


DECALS



ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	540160	Located under steering wheel, on console	1
2	540030	Located on scarifier where shown	2
3	540170	Located on inside of left cab panel	1
4	540040	Located on outside of left cab panel	1
5	540000	Located under steering wheel on console	1
6	540180	Located on hood down flange, close to cab	1
7	540050	Located on outside of right cab panel also centered on fuel tank close to filler neck	2
8	540190	Located above steering wheel on tilt console	1
9	540200	Located on inside of left cab panel, toward front	1
10	540210	Located on both right and left cab panels, plus center one on fuel tank and one on hyd. oil reservoir	4
11	540220	Located on valve control support panel, align to correct valve function	1
12	540230	Located on valve control support panel, align to correct valve function	1
13	540240	Located on instrument panel, align to correct function	1
14	540250	Located under steering wheel, on console	1
15	540260	Located under steering wheel, on console	1
16	540270	Located ahead of throttle	1
17	540280	Located ahead of parking brake	1
18	540290	Located center on tool box lid	1
19	151090	Located on canopy support, both sides	2
20	540300	Located on boom as shown and on right corner of rear down flange hood	3
21	151100	Located as shown and centered on rear hood panel	3
22	151050	Located center on battery box, face to rear	1
23	540090	Located as shown	A/S
24	540310	Located under steering wheel, on console	1